

ACTIVATEDDECOR

Toll Free: 1-877-543-8711 www.activateddecor.com Email: info@activateddecor.com

Installation & Set-Up Instructions

1. Position lift in cabinet and screw or bolt securely in place. Make certain lift is level!
2. Plug the system into a 110 VAC power source.
3. Operate lift in the up direction. See note below.
4. Mount TV to mechanism.
5. Attach lid to floating lid support plate. Using an Allen Wrench, set stop collars at desired location. Note: If your control is.....Low Voltage (flying leads): Hold wires together. RF: Press and release button on hand-held transmitter. IR : Press "up" button on your universal remote control.

Setting Up/Down Limits Using Hand-Held Programmable Switch

1. Unplug existing "switch lead" from the post's control box.
2. Plug "programmable switch" into control box.
3. Use the "arrows" on the switch to raise lift to desired up location.
4. Press "S", release, and then press "1". You've set the up limit stop.
5. Use the "arrows" on the switch to lower lift to desired down location.
6. Press "S", release, and then press "2". You've set the down limit stop.
7. After setting limit stop points, DO NOT use the arrow keys to operate the mechanism. Press #1 for Up and press #2 for down.
8. Unplug programmable switch from control box and replace with original switch lead.

Programming Your Universal Remote Control

2 Channel IR Interface

1. Point the IR LED at the Universal Remote Control and place it in "Learn" mode.
2. Slide the PGM switch to the ON position to program relay one. (up) The green LED will flash on and off.
3. The Universal Remote should beep or give some other indication that it has received the code generated by the board.
4. To program relay two, (down) turn on DIP switch position 7, SEL1, and follow the same procedure.
5. When finished, turn off the PGM switch.